



**50-687**

**4-Lug Adapter**

Fits most small cars with 4-lug patterns. Revision 12: 4 on 90.1mm, 94.1, 96, 98, 100, 4", 104, 108, 4.5" patterns.



**50-688**

**5-Lug Adapter - Small**

Fits many cars with smaller 5 lug patterns. Revision 12: 5 on 98mm, 100, 105, 106.4, 108, 112, 115, 118, 120mm patterns.



**50-693**

**5-Lug Adapter - Large**

Fits 5 Lug cars, smaller SUVs & trucks. Revision 4: 5 on 114mm, 4.5", 115mm, 120mm, 4.75", 127mm, 130mm patterns.



**50-946**

**Light Duty 6 Lug Adapter**

6 lug adapter fits some GM vehicles and some single wheel Sprinters. Revision 1 : 6 on 4.5", 115mm, 120mm, 4.75", 127mm, 130mm patterns.



**50-681**

**4, 5, & 6 Lug 1/2-Ton Truck w/Import**

Fits many 1/2 ton pick ups including Toyota & Chevy. Also fits some larger European vehicles. Revision 4: 4 on 5.5", 4 on 160mm, 5 on 5.5", 5 on 150mm, 6 on 5.5" patterns.



**50-694**

**6 & 7 Lug Truck Adapter with F150**

Has many 1/2-ton truck and SUV patterns. Revision 1: 6 on 132mm, 6 on 5.5", 6 on 135mm, 7 on 150mm patterns.



**50-683**

**8 & 10 Truck Adapter**

Fits 3/4 and 1-ton applications such as GM 2500HD and Ford F350. Revision 9: 8 on 6.5", 8 on 170mm, 8 on 180mm, 10 on 7.25" patterns.



**50-935**

**Dual Wheel Truck Adapter**

Fits many 1 ton dual wheel trucks. May require the use of additional stud extensions and a reach plate for rear rotors. Revision 9: 5 on 6.34", 6 on 6.5", 8 on 170mm, 8 on 200mm, 8 on 210mm, 8 on 225mm, 10 on 7.25", 10 on 222.25mm, 10 on 225mm patterns.



**50-691**

**4, 5, & 6 Lug 1/2-Ton Truck**

1/2 ton truck adapter, includes pre-2004 Ford F150. Revision 9: 4 on 5.5", 5 on 135mm, 5 on 5.5", 6 on 5.5" patterns.



**50-246**

**Small Spacer Ring**

Spacer for use with smaller 4 and 5 lug adapters.



**30-791**

**Larger Spacer Ring**

Large spacer for use with single wheel truck adapters.



**50-046**

**Standard Nose Cone Extension**

For use when cutting head gear box or feed screw interferes with vehicle or feed screw interferes with vehicle.



**50-049**

**Double-thick Nose Cone Extension**

Used where high offset is required for lathe to vehicle, or lathe to lift interference.



**50-1020**

**Mini Adapter**

MINI adapter includes 4 x 100 and 5 x 120 patterns.



**50-1021**

**European Tall Adapter**

5 X 108, 5 X 112, & 5 X 120 patterns that fit BMW, MINI, Mercedes, Volvo, and VW and several other vehicles with these patterns.



**50-1022**

**Asian Tall Adapter**

Increases offset for many Asian cars. Revision 1: 4 on 100mm, 4 on 114.3mm, 5 on 100mm, 5 on 112mm, 5 on 114.3mm, 5 on 120mm patterns.



**50-3ADPHON**

**Honda Adapter Kit**

Set includes 3 nickel plated adapters with Honda lug nut contoured holes. 50-996: 4 on 100 w/ 56mm center hole, 50-997: 5 on 114.3mm & 5 on 120mm w/64mm center hole, and 50-998: 5 on 114.3mm w/72mm center hole.



**50-695**

**Older Alternate 4, 5, & 6 Lug Adapter**

Fits many cars and the lightest trucks. Revision 6: 4 on 4.75", 5 on 4.5", 5 on 4.75", 5 on 5", 6 on 4.5", 6 on 5" patterns.



**50-689**

**3 Lug Adapter**

Revision 3: 3 on 98mm, 112mm, 114.3mm, 120mm, 130mm, 150mm, 160mm patterns.



**50-940**

**European 5 Lug Adapter**

Alternate Euro adapter includes 5 x 114.3 mm, and 5 x 120mm patterns.



### 50-939

#### Alternate Dual Wheel Adapter

Fits many Asian Dual wheel trucks such as Mitsubishi and Isuzu. Revision 1: 5 on 203mm, 5 on 208mm, 6 on 8.75" patterns.



### 50-955

#### 1-Ton High Hat Adapter

Dual wheel truck adapter for rear axle. No stud extensions required. Use with correct reach extension plate for your lathe model. Rev. 1: 8 on 200mm, 210mm, 225mm and 10 on 225mm patterns.



### 50-TRANSIT

#### Ford Transit Adapter Kit

Fits full size Ford Transit single and dual wheel models. Includes Rev. 7 50-696 adapter (5 on 155mm, 160mm, 165mm, 170mm) and Rev. 1 50-934 adapter (5 on 170mm, 190mm, & 6 on 180mm, 205mm, 222.3mm, 245mm), and 3) 50-962 spacers.



### 50-999KIT

#### Medium-Duty Dual-Wheel Truck Kit

Has 8 on 275mm and 10 on 11.25" patterns. Fits most medium duty trucks and buses. Complete kit for front & rear includes 1) 50-944 adapter, 1) 50-999 adapter, 5) 50-986 M20 nuts, 5) 50-987 M22 nuts, 5) 50-960 25mm spacers, 10) 50-961 8mm spacers.



### 50-TRK955

#### Dual Wheel Truck Kit Revision 2

For front & rear 3/4 & 1 ton trucks from Ford, GM, & Ram. Includes 50-683, 50-935, 50-955 adapters, and 50-1492 reach plate. Fits 9.2, X9, and A10 lathes only.



### 50-989

#### HD Adapter

HD adapter with 10x335 pattern. Fits many city & charter buses, and larger trucks with heavy axles.



### 50-TRKKIT

#### Dual Wheel Truck Kit Revision 1

For domestic 1 ton dual wheel pick-up chassis trucks 2002 and newer. Includes 50-683, 50-935, 50-1492, and 50-005, 50-007, & 50-009 stud extensions.



### 50-179

#### Nut and Bolt Kit

Includes 5 nuts each of 1/2"x20, 12mmx1.25, 12mmx1.5, 9/16x18, 14mmx1.5, and 30-687 Studs.



### 50-1347KIT

#### Dual Wheel Truck Kit - X9D

For front and rear of 3/4 and 1 ton trucks from Ford, GM, and Ram. Includes 50-683, 50-935, 50-955 adapters, and 50-1347 reach plate for 1330 cutting head.



### 30-687

#### Studs for Fiat / Dodge / Jeep

Studs for late model Fiat 500, Dodge Dart and 200 models. Requires M12 X 1.25 lug nuts from 50-179 kit.



### 50-1492K

#### Ford E&F 350/450/550 Reach Ext. Kit

For rear rotors on dual wheel trucks where additional reach is required. Use with 50-935 adapter and 9.2, X9, and A10 lathes with 50-220 or 50 12XX series cutting heads.



### 50-006

#### GM Hexagonal Stud Extensions

For rear of some 3500 HD GM trucks: 5/8"x18 - 5 per set. For use with 50-935R9 adapter and correct reach extension plate for your lathe model.



### 50-492K

#### Ford E&F 350/450/550 Reach Ext. Kit

Same as 50-1492K, but for 50-220 Speed-Lock cutting head only



### 50-1011

#### Dodge ProMaster Stud Extensions

Stand offs for late model Dodge full size ProMaster. Requires 50-693 adapter and M14 lug nuts from the 50-179 kit.



### 50-1492

#### Reach Extension Plate

Allows lathe to reach rear rotors of medium and heavy duty trucks. For 9.2, X9, and A10 lathes.



### 50-185KIT

#### Mitsubishi Box Truck Rr. Stud Ext.

Kit includes 3 x 50-185L left-hand thread extensions in blue, 3 x 50-185R right-hand thread extensions in red, and 3 x 35-185 adapter pilot bolts. Use with 50-939 adapter.



### 50-1347

#### T-Slot Reach Extension Plate

Reach Extension plate for X9D lathes.



### SuperTech

#### SuperTech App for Pro-Cut Techs.

Free app for Android or iOS. Includes: Adapter Search, Pro-Cut Rep zip search, TrainSMART Training, Videos, Diagrams, and Tech Manuals.