




TECH BULLETIN

#45

TECH SUPPORT: phone: 800-543-6618, Prompt #2 email: service@procutusa.com
 All Pro-Cut technical bulletins: www.procutusa.com/bulletins.aspx
www.procutusa.com  www.facebook.com/procutusa

50-1011 Dodge ProMaster Stand Off Kit



Dodge ProMaster

Machining Rotors on the Dodge ProMaster Van

Machining the rotors on the Dodge ProMaster van requires the following parts:

- * 50-1011 Stand Off Kit
 - * 50-179 Lug Nut Kit with M14 Lug Nuts
 - * 50-681 R3 Adapter or 50-693 Adapter
- As of 2/1/2016 50-681 R4 does not have a 5 on 130 pattern*

Setup:

- * Be sure that the vehicle is in neutral and traction control is properly disengaged.
- * Remove the wheels and calipers from the hub.
- * Install the (5) 50-1011 stand offs.
- * Install the adapter along with the M14 lug nuts from the 50-179 lug nut kit.
- * Attach the Pro-Cut on car brake lathe as trained.



50-1011 Stand Off Kit



50-693 Adapter

OR



50-681 R3 Adapter



50-179 Lug Nut Kit

Contact the Pro-Cut Service Department at 800.543.6618, Prompt #2, with any questions.

PRO-CUT INTERNATIONAL is the world leader in rotor matching systems and on-car brake lathes. The company is located in West Lebanon, NH.